


# 2027 KT1000 TRANS4x4

## PARTS DIAGRAM

### Fuel Pump



# 2027 KT1000 TRANS4x4

## PARTS LIST

### Fuel Pump

| ITEM NAME                             | PART NUMBER | QUANTITY |
|---------------------------------------|-------------|----------|
| PLATE (Ref # 13272)                   | 13272-2500  | 1        |
| COVER (Ref # 14092)                   | 14092-1044  | 1        |
| INSULATOR (Ref # 16073)               | 16073-0129  | 2        |
| PIPE,FUEL (Ref # 32155)               | 32155-7380  | 1        |
| FILTER-FUEL (Ref # 49019)             | 49019-0013  | 1        |
| NOZZLE-INJECTION (Ref # 49033)        | 49033-0040  | 2        |
| PUMP-FUEL (Ref # 49040)               | 49040-0832  | 1        |
| PIPE-INJECTION (Ref # 49056)          | 49056-0566  | 1        |
| TUBE-ASSY,TANK-PIPE (Ref # 51044)     | 51044-1260  | 1        |
| TUBE-ASSY,PIPE-ENGINE (Ref # 51044A)  | 51044-1261  | 1        |
| CHAMBER-FUEL (Ref # 51072)            | 51072-0003  | 1        |
| RING-O,INJECTION NOZZLE (Ref # 92055) | 92055-0937  | 2        |
| BOLT,FLANGED,5MM (Ref # 92153)        | 92153-0361  | 2        |
| BOLT,FUEL PUMP (Ref # 92154)          | 92154-1326  | 6        |
| CLAMP,FUEL PIPE (Ref # 92173)         | 92173-1213  | 6        |
| CLAMP (Ref # 92173A)                  | 92173-2551  | 1        |
| O RING (Ref # 670)                    | 670E5090    | 1        |