


# 2009 Vulcan® 1700 Nomad™

## PARTS DIAGRAM

### Ignition Switch/Locks/Reflectors



# 2009 Vulcan® 1700 Nomad™

## PARTS LIST

### Ignition Switch/Locks/Reflectors

ITEM NAME	PART NUMBER	QUANTITY
BOLT-FLANGED,5X16 (Ref # 130)	130BA0516	2
SCREW-CSK-CROSS,6X30 (Ref # 221)	221AA0630	2
SCREW-PAN-WS-CROS,5X10 (Ref # 223)	223AB0510	2
SCREW-PAN-WSP-CROS,4X12 (Ref # 225)	225AB0412	1
BRACKET,CRUISE CONTROL SWITCH (Ref # 11055)	11055-0609	1
ROTOR,PANNIER LOCK (Ref # 21007)	21007-5065	2
SWITCH-ASSY-IGNITION (Ref # 27005)	27005-0052	1
KEY-LOCK,BLANK (Ref # 27008)	27008-1211	1
SWITCH,SIDE STAND (Ref # 27010)	27010-0088	1
SWITCH,REAR BRAKE (Ref # 27010A)	27010-0089	1
SWITCH,CRUISE CONTROL (Ref # 27010B)	27010-0090	1
LOCK-ASSY,SEAT STRIKER (Ref # 27016)	27016-1098	1
LOCK-ASSY,HELMET (Ref # 27016A)	27016-5311	2
LOCK-ASSY,SEAT (Ref # 27016B)	27016-5359	1
SWITCH-ASSY (Ref # 27045)	27045-5404	1
CAP-TANK,FUEL (Ref # 51049)	51049-5004	1
SCREW,5X12 (Ref # 92009)	92009-1296	2
NUT,5MM (Ref # 92015)	92015-1710	2
SPRING,REAR BRAKE SWITCH (Ref # 92144)	92144-1141	1
BOLT,SOCKET,6X35 (Ref # 92151)	92151-1390	1
BOLT,TORX,8X22 (Ref # 92153)	92153-1273	2