


Mule 500

PARTS DIAGRAM

Air Cleaner

E1130



Mule 500

PARTS LIST

Air Cleaner

ITEM NAME	PART NUMBER	QUANTITY
SCREW-PAN-CROS,6X14 (Ref # 220)	220B0614	1
NUT-HEX,6MM (Ref # 311)	311B0600	2
WASHER-PLAIN-SMALL,6MM (Ref # 410)	410B0600	2
GASKET (Ref # 11009)	11009-2925	1
CASE-AIR FILTER (Ref # 11011)	11011-1367	1
ELEMENT-ASSY-AIR FILTER (Ref # 11029)	11029-1004	1
DUCT,AIR FILTER (Ref # 14073)	14073-1453	1
DUCT,AIR INTAKE (Ref # 14073A)	14073-1491	1
COVER,AIR FILTER (Ref # 14090)	14090-1106	1
PIPE-INTAKE (Ref # 16060)	16060-2151	1
BOOT (Ref # 49006)	49006-1199	1
BOLT,6X25,W/WASHER (Ref # 92001)	92001-1140	2
NUT,FLANGED,6MM (Ref # 92015)	92015-1193	1
CLAMP (Ref # 92037)	92037-1460	1
CLAMP (Ref # 92037A)	92037-2002	2
CLAMP (Ref # 92037B)	92037-3009	1
CLAMP (Ref # 92037C)	92037-3711	1
CLAMP (Ref # 92037D)	92037-506	1
TUBE (Ref # 92059)	92059-2280	1
SEAL,AIR FILTER (Ref # 92093)	92093-1241	1
SEAL,DUST (Ref # 92093A)	92093-1322	1
CLAMP (Ref # 92170)	92170-1036	1
CLAMP,AIR FILTER (Ref # 92170A)	92170-1211	4