


## 1980 KX420 PARTS DIAGRAM

FRONT HUB/BRAKE



# 1980 KX420 PARTS LIST

## FRONT HUB/BRAKE

| ITEM NAME                       | PART NUMBER   | QUANTITY |
|---------------------------------|---------------|----------|
| PANEL-ASY,FR BRK (Ref # 1)      | 41035-1002    | 1        |
| BOLT-UPSET (Ref # 2)            | 112G0622      | 1        |
| WASHER PLAIN 6MM (Ref # 3)      | 410B0600      | 1        |
| LEVER,FRONT BRAKE CAM (Ref # 4) | 41053-1003    | 1        |
| CAM SHAFT,BRAKE (Ref # 5)       | 41050-1002    | 1        |
| SHOE-BRAKE (Ref # 6)            | 41048-1068    | 2        |
| SPRING-BRAKE SHOE (Ref # 7)     | 42020-004     | 2        |
| DRUM-ASSY,FR BRK,BLK (Ref # 8)  | 41034-1006-21 | 1        |
| CIRCLIP,42MM (Ref # 9)          | 92033-1041    | 1        |
| BEARING,FRONT DRUM (Ref # 10)   | 92045-033     | 2        |
| COLLAR,FRONT BRAKE (Ref # 11)   | 92027-1034    | 1        |
| COLLAR,FRONT AXLE (Ref # 12)    | 92027-1035    | 1        |
| COLLAR,FRONT AXLE (Ref # 13)    | 92027-1178    | 1        |
| AXLE,FRONT (Ref # 14)           | 41068-1006    | 1        |
| BOLT,SOCKET,10X45 (Ref # 15)    | 92001-1202    | 1        |
| "O" RING,15MM (Ref # 16)        | 670B2015      | 1        |