


2000 Vulcan 1500 Nomad PARTS DIAGRAM

Fuel Tank(4/4)

F2410



2000 Vulcan 1500 Nomad PARTS LIST

Fuel Tank(4/4)

ITEM NAME	PART NUMBER	QUANTITY
GASKET,FUEL GAUGE (Ref # 11009)	11009-1656	1
COVER,FUEL GAUGE (Ref # 14090)	14090-1624	1
COVER,METER (Ref # 14090A)	14090-1674	1
PACKING,TAP VALVE (Ref # 43049)	43049-1066	1
TAP-ASSY,FUEL (Ref # 51023)	51023-1226	1
CAP-TANK,FUEL (Ref # 51049)	51049-1103	1
BOLT-FLANGED,8X30 (Ref # 130)	130H0830	1
BOLT-FLANGED,8X35,BLACK (Ref # 130A)	130J0835	1
SCREW-PAN-CROS (Ref # 220)	220B0308	2
SCREW-PAN-CROS (Ref # 220A)	220D0510	2
TUBE-RUBBER,7X10X860 (Ref # 702)	702A07860	1
GAUGE,FUEL (Ref # 52005A)	52005-1129	1
BOLT,6X25 (Ref # 92001)	92001-1524	2
BOLT,FUEL GAUGE (Ref # 92001A)	92001-1705	4
WASHER,6.2X11X1.5 (Ref # 92022)	92022-183	2
WASHER,5.1X10X1.0 (Ref # 92022A)	92022-1977	2
COLLAR,L=19.3 (Ref # 92027)	92027-1780	1
RING-O (Ref # 92055)	92055-1023	2
RING-O,FUEL TAP PACKING (Ref # 92055A)	92055-1112	1
RING-O,TAP LEVER (Ref # 92055B)	92055-1419	1
GROMMET (Ref # 92071)	92071-1187	1
DAMPER,FUEL TANK (Ref # 92075)	92075-125	2
DAMPER (Ref # 92075A)	92075-1736	2
DAMPER,RUBBER (Ref # 92075B)	92075-261	1
COLLAR (Ref # 92152)	92152-1100	1
DAMPER,FUEL TANK (Ref # 92160)	92160-1907	2
DAMPER (Ref # 92160A)	92160-1941	1
TANK-COMP-FUEL,EBONY (Ref # 51001A)	51001-1549-H8	1
TANK-COMP-FUEL,EBONY (Ref # 51001C)	51001-1558-H8	1

2000 Vulcan 1500 Nomad PARTS LIST

Fuel Tank(4/4)

ITEM NAME	PART NUMBER	QUANTITY
CLAMP,TUBE (Ref # 92037)	92037-147	1
CLAMP,TUBE (Ref # 92037)	92037-147	2
SEAL,FUEL TANK CAP (Ref # 92093)	92093-1030	1
TUBE,DRAIN (Ref # 92191)	92191-1272	1