


2018 Z900 PARTS DIAGRAM

Footrests



2018 Z900 PARTS LIST

Footrests

ITEM NAME	PART NUMBER	QUANTITY
WEIGHT,STEP (Ref # 13042)	13042-0022	1
STOPPER (Ref # 32085)	32085-0801	1
STEP,RR,LH (Ref # 34028)	34028-0004	1
STEP,RR,RH (Ref # 34028A)	34028-0005	1
STEP,RUBBER (Ref # 34028B)	34028-0349	1
STEP,FR,LH (Ref # 34028C)	34028-0350	1
STEP,FR,RH (Ref # 34028D)	34028-0351	1
CIRCLIP-TYPE-E,10MM (Ref # 482)	482EA0100	1
CIRCLIP-TYPE-E (Ref # 482A)	482EA5000	1
BOLT,BANK SENSOR (Ref # 92001)	92001-1905	1
PIN,6X40 (Ref # 92043)	92043-0200	1
PIN,12X42.5 (Ref # 92043A)	92043-1594	1
BALL,6.35MM (Ref # 92140)	92140-0008	1
SPRING,STEP RETURN (Ref # 92145A)	92145-0723	1
SPRING (Ref # 92145B)	92145-1319	1
BOLT,SOCKET,5X20 (Ref # 92150)	92150-1019	1
WASHER,16X26X2.3 (Ref # 92200)	92200-0043	1