



2011 MULE™ 600 PARTS DIAGRAM

Shock Absorber(s)

F2280



2011 MULE™ 600 PARTS LIST

Shock Absorber(s)

ITEM NAME	PART NUMBER	QUANTITY
WASHER-SPRING,10MM (Ref # 461)	461DA1000	1
SHOCKABSORBER (Ref # 45014)	45014-0100	1
STRUT (Ref # 45023)	45023-0003	1
NUT,FLANGED,10MM (Ref # 92015)	92015-1428	1
NUT,LOCK,10MM (Ref # 92015A)	92015-1597	1
DAMPER,SHOCKABSORBER (Ref # 92075)	92075-1784	1
SPRING,SHOCK,K=24.5/44.1N/MM (Ref # 92145)	92145-0400	1
BOLT,FLANGED,10X53.5 (Ref # 92153)	92153-1698	1