


2002 NINJA® ZX™-6 PARTS DIAGRAM

Valve(s)

E1210



2002 NINJA® ZX™-6 PARTS LIST

Valve(s)

ITEM NAME	PART NUMBER	QUANTITY
VALVE-INTAKE (Ref # 12004)	12004-1125	1
VALVE-EXHAUST (Ref # 12005)	12005-1226	1
RETAINER-VALVE SPRING (Ref # 12009)	12009-1076	1
RETAINER-VALVE SPRING,IN (Ref # 12009A)	12009-1089	1
COLLET (Ref # 12011)	12011-1052	1
TAPPET (Ref # 12032)	12032-1061	1
TAPPET (Ref # 12032A)	12032-1065	1
SEAT-SPRING (Ref # 16007)	16007-1159	1
SEAT-SPRING (Ref # 16007A)	16007-1160	1
SPRING-ENGINE VALVE,INTAKE,IN (Ref # 49078)	49078-1127	1
SPRING-ENGINE VALVE,INTAKE,OUT (Ref # 49078A)	49078-1145	1
SPRING-ENGINE VALVE,EXHAUST (Ref # 49078B)	49078-1146	1
SEAL-OIL,VALVE GUIDE (Ref # 92049)	92049-1308	1
SHIM,T=2.50 (Ref # 92180)	92180-1014	1
SHIM,T=2.55 (Ref # 92180A)	92180-1016	1
SHIM,T=2.60 (Ref # 92180B)	92180-1018	1
SHIM,T=2.65 (Ref # 92180C)	92180-1020	1
SHIM,T=2.70 (Ref # 92180D)	92180-1022	1
SHIM,T=2.75 (Ref # 92180E)	92180-1024	1
SHIM,T=2.80 (Ref # 92180F)	92180-1026	1
SHIM,T=2.85 (Ref # 92180G)	92180-1028	1
SHIM,T=2.90 (Ref # 92180H)	92180-1030	1
SHIM,T=2.95 (Ref # 92180I)	92180-1032	1
SHIM,T=3.00 (Ref # 92180J)	92180-1034	1
SHIM,T=3.05 (Ref # 92180K)	92180-1036	1
SHIM,T=3.10 (Ref # 92180L)	92180-1038	1
SHIM,T=3.15 (Ref # 92180M)	92180-1040	1
SHIM,T=3.20 (Ref # 92180N)	92180-1042	1
SHIM,T=3.25 (Ref # 92180O)	92180-1044	1

2002 NINJA® ZX™-6 PARTS LIST

Valve(s)

ITEM NAME	PART NUMBER	QUANTITY
SHIM,T=3.30 (Ref # 92180P)	92180-1046	1
SHIM,T=3.35 (Ref # 92180Q)	92180-1048	1
SHIM,T=3.40 (Ref # 92180R)	92180-1050	1
SHIM,T=3.45 (Ref # 92180S)	92180-1052	1
SHIM,T=3.50 (Ref # 92180T)	92180-1054	1