


1980 KZ750-E1 PARTS DIAGRAM

TURN SIGNALS ('80 KZY 50-E1)



1980 KZ750-E1 PARTS LIST

TURN SIGNALS ('80 KZY 50-E1)

ITEM NAME	PART NUMBER	QUANTITY
LAMP ASSY,TURN SIGNAL (Ref # 1)	23040-1017	1
GASKET,TURN SIGNAL (Ref # 2)	11009-1052	2
SCREW-PAN-CROS (Ref # 3)	220E0412	2
LENS-SIGNAL LAMP (Ref # 4)	23048-1022	2
WASHER-PLAIN,4MM (Ref # 5)	23058-002	2
BULB,12V 23/8W (Ref # 6)	92069-060	1
BRACKET FR SGNL LAMP (Ref # 7)	23051-1032	1
BOLT-UPSET (Ref # 8)	112G0630	2
NUT 6MM (Ref # 9)	311B0600	2
WASHER PLAIN 6MM (Ref # 10)	411B0600	2
WASHER SPRING 6MM (Ref # 11)	461F0600	2
LAMP ASSY,TURN SIGNAL (Ref # 12)	23040-1018	1
BULB 12V 32CP (Ref # 17)	92069-055	1
BRACKET,TURN SIGNAL (Ref # 18)	23051-1014	1
NUT 10MM (Ref # 23)	315B1000	1
WASHER-PLAIN,10MM (Ref # 24)	411D1000	1
WASHER SPRING 10MM (Ref # 25)	461F1000	1
COLLAR (Ref # 26)	92027-147	1
DAMPER RUBBER (Ref # 27)	92075-128	1
DAMPER RUBBER,SIG LM (Ref # 28)	92075-158	1