


# 1973 F11M PARTS DIAGRAM

CRANKCASE (73 F11M)



# 1973 F11M PARTS LIST

## CRANKCASE (73 F11M)

ITEM NAME	PART NUMBER	QUANTITY
STUD,10X95 (Ref # 1)	172G1095	
SCREW PAN HEAD 6X65 (Ref # 2)	220B0665	
SCREW PAN HEAD 6X45 (Ref # 3)	220B0645	
CRANKCASE-L.H,F.BLAC (Ref # 4)	14002-085-21	
SEAL-OIL (Ref # 5)	92049-1250	
BEARING BALL #6305 (Ref # 6)	601B6305	
OIL SEAL TB3040 (Ref # 7)	92050-033	
BEARING BALL #6205 (Ref # 8)	601B6205	
HOLDER-MISSION BERNG (Ref # 9)	14014-024	
SCREW PAN HEAD 6X12 (Ref # 10)	220B0612	
PIN,DOWEL,10X8.2X14 (Ref # 11)	92043-1037	
HOLDER-CRANK BEARING (Ref # 12)	14014-019	
SCREW CNTSNK HD 6X16 (Ref # 13)	221B0616	
CRANKCASE-R.H,F.BLAC (Ref # 14)	14003-059-21	
BREATHER ASSY (Ref # 15)	14069-1001	
GROMMET (Ref # 16)	92071-042	
PIPE-BREATHER (Ref # 17)	92059-061	
HOLDER-MISSION BERNG (Ref # 18)	14014-020	
BEARING BALL #6304 (Ref # 19)	601B6304	
HOLDER-MISSION BERNG (Ref # 20)	14014-023	
RECEIVER-OIL (Ref # 21)	14015-004	
BEARING-BALL (Ref # 22)	92045-016	
OIL SEAL,TB38508 (Ref # 23)	653B385008	