


1978 SR

PARTS DIAGRAM

AIR CLEANER



1978 SR

PARTS LIST

AIR CLEANER

ITEM NAME	PART NUMBER	QUANTITY
BAFFLE PLT,AIR CLEANER (Ref # 1)	11019-003	1
WASHER PLAIN 6MM (Ref # 2)	411B0600	4
BOLT-UPSET (Ref # 3)	112G0618	2
FILTER-ASSY (Ref # 4)	11010-1079	1
FILTER-ASSY (Ref # 4)	11010-1079	1
CAP,AIR CLEANER (Ref # 5)	11012-069	1
ELEMENT,AIR CLNR (Ref # 6)	11013-1006	1
HOLDER,INLET PIPE (Ref # 7)	11033-006	1
GASKET,HOLDER (Ref # 8)	11039-003	1
INLET DUCT,#2,3 (Ref # 9)	11015-057	2
INLET PIPE,#1.4 (Ref # 10)	11015-063	2
SPRING COIL (Ref # 11)	92081-047	4
BRACKET,AIR CLEANER (Ref # 12)	32070-038	2
UNAVAILABLE IN PRICE BOOK (Ref # 13)	700Q6200	1
TUBE,BREATHING (Ref # 14)	92059-137	1
CLAMP BREATHING PIPE (Ref # 15)	92037-028	2
WASHER SPRING 6MM (Ref # 16)	461F0600	2
BOLT-UPSET,6X12 (Ref # 17)	112G0612	2