

Swing Arm

Let the Good Times Roll®

Exploded view diagram of a vehicle chassis and suspension assembly. The diagram shows the following components and their part numbers:

- Ref. Crankcase** (Reference Crankcase)
- 92028** (Two locations)
- 92046**
- 11012** (Two locations)
- 42036** (Two locations)
- 92015**
- 11012A** (Two locations)
- 33032**
- 11012A**
- 11012** (Two locations)
- 92002** (Two locations)
- 92015B**
- 554**
- 46102/A**
- 92015B**
- 92002**
- 113**
- 461**
- 12053**
- 222** (Two locations)
- 12053A**
- 33001/A/B**
- 92015A**
- 13070**
- 130**
- 55020/A**
- 92022**
- 180**
- 92009**
- 130A**

A **FRONT** arrow indicates the front of the vehicle.

1990 Mojave 250

PARTS LIST

Swing Arm

ITEM NAME	PART NUMBER	QUANTITY
CAP,SWING ARM (Ref # 11012)	11012-1259	4
CAP,SWING ARM (Ref # 11012A)	11012-1520	2
GUIDE-CHAIN,UPP (Ref # 12053)	12053-1194	1
GUIDE-CHAIN,LWR (Ref # 12053A)	12053-1195	1
GUIDE,CHAIN (Ref # 13070)	13070-1156	1
ARM-COMP-SWING (Ref # 33001A)	33001-1349	1
SHAFT-SWING ARM (Ref # 33032)	33032-1139	1
SLEEVE,SWING ARM (Ref # 42036)	42036-1064	2
ROD,TORQUE (Ref # 46102)	46102-1179	1
GUARD (Ref # 55020)	55020-1227	1
BOLT,10X28 (Ref # 92002)	92002-1733	2
SCREW,6X10,WHITE (Ref # 92009)	92009-1286	2
NUT,14MM (Ref # 92015)	92015-1407	1
NUT,6MM (Ref # 92015A)	92015-1452	2
NUT,LOCK,10MM (Ref # 92015B)	92015-1597	2
WASHER,6.5X20X1.6 (Ref # 92022)	92022-1804	2
BUSHING,SWING ARM (Ref # 92028)	92028-1261	2
BEARING-NEEDLE,TA2030Z (Ref # 92046)	92046-1128	2
BOLT-SMALL-FINE (Ref # 113)	113P1035	2
BOLT-FLANGED,6X40 (Ref # 130)	130G0640	1
BOLT-FLANGED (Ref # 130A)	130G0680	1
BOLT-UPSET-WS (Ref # 180)	180H0614	2
SCREW-CSK-RD-CROS,6X12 (Ref # 222)	222B0612	4
WASHER-SPRING,10MM (Ref # 461)	461F1000	2
PIN-SNAP,10MM (Ref # 554)	554A1000	2