


# 1997 Ninja® ZX™-6R PARTS DIAGRAM

Clutch



# 1997 Ninja® ZX™ -6R PARTS LIST

## Clutch

ITEM NAME	PART NUMBER	QUANTITY
HUB-CLUTCH (Ref # 13087)	13087-1159	1
PLATE-FRICTION (Ref # 13088)	13088-1124	9
PLATE-CLUTCH,T=2.0 (Ref # 13089)	13089-1073	AR
PLATE-CLUTCH,T=2.3 (Ref # 13089A)	13089-1084	8
PLATE-CLUTCH,T=2.6 (Ref # 13089B)	13089-1115	AR
HOLDER,CLUTCH SPRING (Ref # 13091)	13091-1041	4
HOUSING-COMP-CLUTCH (Ref # 13095A)	13095-1335	1
RELEASE-COMP-CLUTCH (Ref # 13102)	13102-1125	1
PLATE-CLUTCH OPERATING (Ref # 13187)	13187-1079	1
ROD,CLUTCH (Ref # 46102)	46102-1371	1
NUT,20MM (Ref # 92015)	92015-1555	1
WASHER (Ref # 92022)	92022-1868	1
SPACER,25.5X47X2.5 (Ref # 92026)	92026-022	1
SPACER (Ref # 92026A)	92026-1356	1
BUSHING (Ref # 92028)	92028-1741	1
BEARING-BALL,6001C3ML01 (Ref # 92045)	92045-1235	1
BEARING-NEEDLE (Ref # 92046)	92046-1231	1
SPRING,FRICTION PLATE (Ref # 92144)	92144-1854	1
SPRING,CLUTCH OPERATING (Ref # 92144A)	92144-1881	4
BOLT,CLUTCH OPERATING (Ref # 92150)	92150-1855	4
WASHER,FRICTION PLATE (Ref # 92200)	92200-1260	1