


1977 KD100-M2

PARTS DIAGRAM

FOOTRESTS/STAND/BRAKE PEDAL

Kawasaki
Let the Good Times Roll®



1977 KD100-M2

PARTS LIST

FOOTRESTS/STAND/BRAKE PEDAL

ITEM NAME	PART NUMBER	QUANTITY
BAR,L.H FOOTREST (Ref # 1)	34028-024	
PIN-FOOTREST BAR FIT (Ref # 2)	92043-080	
PIN COTTER 2.5X16 (Ref # 3)	550D2516	
SPRING,FOOTRESTBAR (Ref # 4)	92083-027	
BAR,R.H FOOTREST (Ref # 5)	34028-023	
BAR,FOOTREST (Ref # 6)	34002-047	
BOLT-SMALL-UPSET,8X18 (Ref # 7)	115G0818	
WASHER SPRING 6MM (Ref # 8)	461F0600	
STAND-SIDE (Ref # 9)	34024-1013	
STAND-SIDE (Ref # 9)	34024-1013	
BOLT,HEX HEAD,10X25 (Ref # 11)	113G1025	
BOLT,10X28 (Ref # 11)	113G1028	
NUT,10MM (Ref # 12)	314B1000	
PEDAL,BRAKE (Ref # 13)	43001-062	
SPRING-BRAKE PEDAL (Ref # 14)	43005-020	
WASHER BRAKE PEDAL (Ref # 15)	92022-085	
UNAVAILABLE IN PRICE BOOK (Ref # 16)	530D3030	
WASHER PLAIN 6MM (Ref # 17)	410B0600	
PIN COTTER 2.0X15 (Ref # 18)	550D2015	
ROD ASSY,REAR BRAKE (Ref # 19)	43010-5004	
SPRING,BRAKE ROD (Ref # 20)	43012-001	
PIN BRAKE (Ref # 21)	92043-039	
NUT-BRAKE ROD ADJUST (Ref # 22)	92015-042	