




1977 KE250-B1

PARTS DIAGRAM

FOOTRESTS/STAND/BRAKE PEDAL

Kawasaki
Let the Good Times Roll®



1977 KE250-B1

PARTS LIST

FOOTRESTS/STAND/BRAKE PEDAL

ITEM NAME	PART NUMBER	QUANTITY
PIN,FOOTREST BAR FIT (Ref # 1)	92043-115	2
STEP,FOOTREST,L.H (Ref # 2)	34028-037	1
HOLDER,FOOTREST,L.H (Ref # 3)	34003-067	1
SPRING,L.H,FOOTREST (Ref # 4)	92081-1254	1
WASHER PLAIN 8MM (Ref # 5)	410B0800	2
PIN COTTER 2.5X16 (Ref # 6)	550D2516	2
WASHER SPRING 14MM (Ref # 7)	461F1400	2
NUT 14MM (Ref # 8)	315B1400	2
STEP,FOOTREST,R.H (Ref # 9)	34028-038	1
HOLDER,FOOTREST,R.H (Ref # 10)	34003-068	1
SPRING,R.H,FOOTREST (Ref # 11)	92081-1255	1
PLATE,FOOTREST (Ref # 12)	13169-1018	1
BOLT, SIDE STAND FIT (Ref # 13)	92003-157	1
SPRING,SIDE STAND (Ref # 14)	34025-008	1
STAND-SIDE (Ref # 15)	34024-064	1
NUT 10MM (Ref # 16)	315B1000	1
PISTON,STD (Ref # 17)	13001-072	1
SPRING BRAKE PEDAL (Ref # 18)	43005-032	1
SCREW PAN HEAD 6X12 (Ref # 19)	220B0612	1
WASHER SPRING 6MM (Ref # 20)	461F0600	1
WASHER,PLAIN,6MM (Ref # 21)	92022-284	1
"O" RING,16MM (Ref # 22)	670B2016	2
NUT 6MM (Ref # 23)	311B0600	1
BOLT-HEX HEAD,6X32 (Ref # 24)	110N0632	1
RUBBER,FOOTREST (Ref # 25)	92076-027	2
WASHER-PLAIN (OPT) (Ref # 26)	92022-199	2
PIN,COTTER,2.0X12 (Ref # 27)	550D2012	2
BRACKET,REAR FOOTREST (Ref # 28)	34029-011	2
PIN (Ref # 29)	92043-1464	2

1977 KE250-B1

PARTS LIST

FOOTRESTS/STAND/BRAKE PEDAL



ITEM NAME	PART NUMBER	QUANTITY
WASHER SPRING 10MM (Ref # 30)	461F1000	2
NUT,10MM (Ref # 31)	314B1000	2