

2007 Ultra 250X


PARTS DIAGRAM

Ignition System

Kawasaki

Let the Good Times Roll®

E1830



2007 Ultra 250X

PARTS LIST

Ignition System

ITEM NAME	PART NUMBER	QUANTITY
BOSS,CAM SENSOR (Ref # 13061)	13061-1687	1
ROTOR,EX CAM (Ref # 21007)	21007-3742	1
ROTOR,PULSING (Ref # 21007A)	21007-3744	1
COIL-IGNITION (Ref # 21121)	21121-3722	2
CORD-ASSY,#1,L=340 (Ref # 21150)	21150-3727	1
CORD-ASSY,#2,L=450 (Ref # 21150A)	21150-3728	1
CORD-ASSY,#3,L=540 (Ref # 21150B)	21150-3729	1
CORD-ASSY,#4,L=600 (Ref # 21150C)	21150-3730	1
SENSOR,TEMP (Ref # 21176)	21176-1077	1
COIL-PULSING (Ref # 59026)	59026-3702	1
BOLT,6X16 (Ref # 92002)	92002-3728	1
SCREW,5X12 (Ref # 92009)	92009-1296	4
NUT,6MM (Ref # 92015)	92015-3767	2
WASHER,PLAIN (Ref # 92022)	92022-3026	1
CLAMP,HOSE (Ref # 92037)	92037-1603	3
PIN (Ref # 92043)	92043-1575	1
RING-O (Ref # 92055)	92055-1639	1
PLUG-SPARK,PMR9B(NGK) (Ref # 92070)	92070-3707	4
BAND,L=188.85 (Ref # 92072)	92072-0105	2
BAND (Ref # 92072A)	92072-3874	1
BOLT,6X18 (Ref # 92150)	92150-1645	1
BOLT,6X70 (Ref # 92150A)	92150-3753	2
COLLAR (Ref # 92152)	92152-3738	4
BOLT-FLANGED,8X25 (Ref # 130)	130CD0825	1
ROLLER,4X8 (Ref # 610)	610A0408	1